



MODELLI - MODELS
















Piatto AD HOC - Profilo FLAT



Istruzioni di montaggio - Assembling instructions

1



														
B01	x	1	1	2	6	1	1	1	1	1	2	x	1	x
B02	1	1	2	4	6	2	2	x	1	1	2	x	1	x
B04	x	2	2	4	6	2	2	x	1	1	4	x	2	x
B08	x	1	1	2	6	1	1	1	1	1	x	2	x	1
B09	1	1	2	4	6	2	2	x	1	1	x	2	x	1
B10	x	2	2	4	6	2	2	x	1	1	x	4	x	2



2



B01  
B08

B02  
B04  
B09  
B10


3




B01  
B08

B02  
B04  
B09  
B10

4




5




B01  
B02  
B04  
B08  
B09  
B10

6




B01  
B08

7




B01  
B08

8



B01  
B08

9



B01  
B08

